


Some Suggested Uses for EMR Defender

IMPORTANT: Do NOT adhere EMR Defender(s) to a device's screen or to any glass surface on your device. Replace after 1 year of use.

 <p>Cellular Phone - 1 Defender</p> <ul style="list-style-type: none"> • 1 Defender over battery compartment 	 <p>Cordless Phone - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender on base station, close to antenna • 1 Defender on phone, close to antenna
 <p>Smart Meter - 4 Defenders</p> <ul style="list-style-type: none"> • 4 Defenders on the front panel or face of the meter 	 <p>Wireless Headset - 1 Defender</p> <ul style="list-style-type: none"> • 1 Defender over battery compartment
 <p>Laptop Computer - 1 Defender</p> <ul style="list-style-type: none"> • 1 Defender, top-centered on the outside of the display panel 	 <p>Desktop Computer - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender on computer tower (top, front or side) • 1 Defender on monitor (centered on top or bottom)
 <p>Game Consoles – 2+ Defenders</p> <ul style="list-style-type: none"> • 1 Defender centered on top of console • 1 Defender on bottom of each controller 	 <p>Television - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender centered above TV screen • 1 Defender centered below TV screen
 <p>Microwave - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender on both the top-left and top-right corners, close to door seals 	 <p>Wireless Router - 2 Defenders</p> <ul style="list-style-type: none"> • 2 Defenders, on the top of the router, close to the antenna(s)
 <p>Alarm Clock - 1 Defender</p> <ul style="list-style-type: none"> • 1 Defender on face or top of alarm clock 	 <p>Vacuum Cleaner - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender on handle • 1 Defender on housing (main body of vacuum)
 <p>Refrigerator - 2 Defenders</p> <ul style="list-style-type: none"> • 1 Defender (front-top-center of the unit) • 1 Defender (front-bottom-center of the unit) 	 <p>Hair Dryer - 1 Defender</p> <ul style="list-style-type: none"> • 1 Defender on any flat surface of hair dryer that remains relatively cool
<p>This list is by no means exclusive. All electrical devices can benefit from EMR Defenders. Feel free to experiment and use the EMR Defender anywhere you want to block EMR's!</p>	